

# *Sensory Harp by Vance Pennington*

## *Tuning Chart*

**Sensory Harp Tuning and String Gauges for Sensory Tuning (Key of C, Chords C & Am.). Your Sensory Harp comes pre-tuned to the more desirable Verdi tuning at 432 Hz.**

**Set Chromatic Tuner to 432 Hz. (aka 'Verdi' Tuning) for slightly lower, more relaxing, sounding notes (Recommended for meditation and relaxation).**

**OR:-**

**Set Chromatic Tuner to 440 Hz. or use a piano/electronic keyboard. (Modern Standard Pitch)**

String #	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22
Gauge	.012	.014	.016	.018	.024	.024	.026	.032	.042	.048	.056	.056	.048	.042	.032	.026	.024	.024	.018	.016	.014	.012
Notes	E5	D5	C5	A4	G4	E4	D4	C4	G3	E3	C3	C3	G3	A3	C4	D4	E4	G4	A4	C5	D5	G5

**Note: If you have a problem replacing or tuning any particular string, take your Sensory Harp to your local music store and seek their advice. Alternatively, take your tuning chart and ask for a suitable, alternative, ball-end guitar string.**

**Alternate Tunings - Please request at time of purchase. (These tunings can be obtained with various string changes)**

<b>Body &amp; Spirit Tuning (Blended Modal):</b>																						
String #	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22
Notes	G5	E5	C5	A4	G4	E4	D4	C4	G3	E3	C3	D3	F3	G3	A3	D4	F4	G4	Bb4	D5	F5	A5

<b>Relaxing/Vocal Tuning (Blended Modal – Tonic/Dominant):</b>																						
String #	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22
Notes	G5	E5	D5	C5	G4	E4	C4	A3	G3	E3	C3	D3	F3	A3	C4	D4	F4	A4	A4	D5	E5	F5

<b>Oriental Meditation Tuning (Blended Modal):</b>																						
String #	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22
Notes	G5	F#5	E5	C#5	B4	G4	F#4	E4	B3	G3	E3	D3	G3	B3	D4	G4	A4	B4	D5	E5	G5	A5